



# **3Com AP9152 and AP9552 Access Points**

## **Quick Configuration Guide**

Manual Version: 6W101

[www.3com.com](http://www.3com.com)

3C Number:

3CRWE955275(Fat Mode)

3CRWE915275(Fat Mode)

**3Com Corporation**

350 Campus Drive, Marlborough, MA, USA 01752 3064

Copyright © 2009-2010, 3Com Corporation. All rights reserved. No part of this documentation may be reproduced in any form or by any means or used to make any derivative work (such as translation, transformation, or adaptation) without written permission from 3Com Corporation.

3Com Corporation reserves the right to revise this documentation and to make changes in content from time to time without obligation on the part of 3Com Corporation to provide notification of such revision or change.

3Com Corporation provides this documentation without warranty, term, or condition of any kind, either implied or expressed, including, but not limited to, the implied warranties, terms or conditions of merchantability, satisfactory quality, and fitness for a particular purpose. 3Com may make improvements or changes in the product(s) and/or the program(s) described in this documentation at any time.

If there is any software on removable media described in this documentation, it is furnished under a license agreement included with the product as a separate document, in the hard copy documentation, or on the removable media in a directory file named LICENSE.TXT or !LICENSE.TXT. If you are unable to locate a copy, please contact 3Com and a copy will be provided to you.

## **UNITED STATES GOVERNMENT LEGEND**

*If you are a United States government agency, then this documentation and the software described herein are provided to you subject to the following:*

All technical data and computer software are commercial in nature and developed solely at private expense. Software is delivered as "Commercial Computer Software" as defined in DFARS 252.227-7014 (June 1995) or as a "commercial item" as defined in FAR 2.101(a) and as such is provided with only such rights as are provided in 3Com's standard commercial license for the Software. Technical data is provided with limited rights only as provided in DFAR 252.227-7015 (Nov 1995) or FAR 52.227-14 (June 1987), whichever is applicable. You agree not to remove or deface any portion of any legend provided on any licensed program or documentation contained in, or delivered to you in conjunction with, this User Guide.

Unless otherwise indicated, 3Com registered trademarks are registered in the United States and may or may not be registered in other countries.

3Com and the 3Com logo are registered trademarks of 3Com Corporation.

All other company and product names may be trademarks of the respective companies with which they are associated.

## **ENVIRONMENTAL STATEMENT**

It is the policy of 3Com Corporation to be environmentally-friendly in all operations. To uphold our policy, we are committed to:

Establishing environmental performance standards that comply with national legislation and regulations.

Conserving energy, materials and natural resources in all operations.

Reducing the waste generated by all operations. Ensuring that all waste conforms to recognized environmental standards. Maximizing the recyclable and reusable content of all products.

Ensuring that all products can be recycled, reused and disposed of safely.

Ensuring that all products are labeled according to recognized environmental standards.

Improving our environmental record on a continual basis.

### **End of Life Statement**

3Com processes allow for the recovery, reclamation and safe disposal of all end-of-life electronic components.

### **Regulated Materials Statement**

3Com products do not contain any hazardous or ozone-depleting material.

### **Environmental Statement about the Documentation**

The documentation for this product is printed on paper that comes from sustainable, managed forests; it is fully biodegradable and recyclable, and is completely chlorine-free. The varnish is environmentally-friendly, and the inks are vegetable-based with a low heavy-metal content.

# About This Manual

## Organization

3Com AP9152 and AP9552 Access Points Quick Configuration Guide is organized as follows:

Chapter	Contents
1 Logging In to the Web Interface	Describes how to logging in to the web interface.
2 Setting IP Address	Describes how to setting IP address.
3 WLAN Service Configuration	Describes the detailed configuration procedures for wireless service configuration, access service based VLAN configuration, PSK (WPA or WPA2) authentication, local MAC authentication, remote MAC authentication, remote 802.1X authentication and 802.11n configuration.
4 WDS Configuration	Describes the detailed configuration procedures for WDS and WDS point-to-multipoint.
5 Repeater Mode Configuration	Describes the detailed configuration procedures for repeater mode.
6 Workgroup Bridge Mode Configuration	Describes the detailed configuration procedures for workgroup bridge mode.
7 Save Configuration over reboot	Describes how to save configuration.

## Conventions



The manual uses the following conventions:

### GUI conventions

Convention	Description
<b>Boldface</b>	Window names, button names, field names, and menu items are in Boldface. For example, the <b>New User</b> window appears; click <b>OK</b> .
>	Multi-level menus are separated by angle brackets. For example, <b>File &gt; Create &gt; Folder</b> .

Convention	Description
< >	Button names are inside angle brackets. For example, click <OK>.
[ ]	Window names, menu items, data table and field names are inside square brackets. For example, pop up the [New User] window.
/	Multi-level menus are separated by forward slashes. For example, [File/Create/Folder].

## Symbols

Convention	Description
 <b>Caution</b>	Means reader be careful. Improper operation may cause data loss or damage to equipment.
 <b>Note</b>	Means a complementary description.

## Related Documentation

In addition to this manual, each 3Com AP9152 and AP9552 Access Points documentation set includes the following:

Manual	Description
3Com AP9552 Dual Band 802.11n PoE Access Point Quick Installation Guide	Introduces the hardware configuration, installation preparations, and installation of the 3Com AP9552 indoor WLAN access point.
3Com AP9152 Single-Band 802.11n PoE Access Point Quick Installation Guide	Introduces the hardware configuration, installation preparations, and installation of the 3Com AP9152 indoor WLAN access point.
3Com AP9152 and AP9552 Access Points Web-Based Configuration Manual	This manual guides you to configure 3Com AP9152 and AP9552 Access Points through the Web interface.  For how to quickly set up your device, see <i>3Com AP9152 and AP9552 Access Points Quick Configuration Guide</i> . For how to log in to the Web management interface, see <i>Web Overview</i> . For how to configure a software feature through the Web interface, and corresponding configuration examples, see the specific configuration document for the feature.
3Com AP9152 and AP9552 Access Points User Manual	This manual guides you to configure 3Com AP9152 and AP9552 Access Points at the command line interface.  For manual organization and feature overview, see <i>Documentation Guide</i> . For specific software feature overview, detailed configuration procedures, and configuration examples, see <i>Operation Manual</i> . For a complete description of all command lines and the command index, see <i>Command Manual</i> .

## Obtaining Documentation

You can access the most up-to-date 3Com product documentation on the World Wide Web at this URL:  
<http://www.3com.com>.

# Table of Contents

<b>1 Logging In to the Web Interface</b> .....	<b>1-1</b>
Logging In to the Web Interface.....	1-1
<b>2 Setting IP Address</b> .....	<b>2-1</b>
Setting IP Address .....	2-1
<b>3 WLAN Access Configuration</b> .....	<b>3-1</b>
Wireless Service Configuration Example.....	3-1
Access Service Based VLAN Configuration Example .....	3-3
PSK Authentication Configuration Example .....	3-5
Local MAC Authentication Configuration Example .....	3-7
Remote MAC Authentication Configuration Example .....	3-10
Remote 802.1X Authentication Configuration Example.....	3-18
802.11n Configuration Example.....	3-26
<b>4 WDS Configuration</b> .....	<b>4-1</b>
WDS Configuration Example .....	4-1
WDS Point-to-Multipoint Configuration Example .....	4-4
<b>5 Repeater Mode Configuration</b> .....	<b>5-1</b>
Repeater Mode Configuration Example.....	5-1
<b>6 Workgroup Bridge Mode Configuration</b> .....	<b>6-1</b>
Workgroup Bridge Mode Configuration Example .....	6-1
<b>7 Save Configuration over reboot</b> .....	<b>7-1</b>
Save Configuration to File.....	7-1



#### Note

- The displayed web pages may vary depending on your device model.
- If a function or parameter is grayed out, it is either not supported or cannot be modified.
- The Console default setting is 9600, 8, N, 1.

# 1 Logging In to the Web Interface

## Logging In to the Web Interface

To enter the web configuration page when the device starts with the null configuration, you need to select the country/region code after login, and then click Apply, as shown in [Figure 1-1](#).

**Figure 1-1** Select a country/region

The screenshot shows a web interface with a blue information icon and the text "You must select a country/region." Below this is a horizontal line, followed by a label "Country/Region:" and a dropdown menu. The dropdown menu is currently set to "NO\_COUNTRY\_SET NA". Below the dropdown menu is another horizontal line, and at the bottom right, there is a button labeled "Apply".

The device is provided with the default Web login information. You can use the default information to log in to the Web interface. The default Web login information is:

- Username: admin
- Password: password
- IP address of the device: 192.168.0.50.

On the PC, open the browser, type the IP address `http://192.168.0.50` in the address bar, press **Enter** and you can enter the login page of the Web interface, as shown in [Figure 1-2](#). Input the username **admin**, password **password**, and the verification code, select the language, and click **Login**.

**Figure 1-2** Login page of the Web interface



---

**⚠ Caution**

- The PC where you configure the device is not necessarily the Web-based network management terminal. A Web-based network management terminal is a PC (or another terminal) used to log in to the Web interface and is required to be reachable to the device.
  - After logging in to the Web interface, you can create a new user and configure the IP address of the interface connecting the user and the device.
  - If you click the verification code displayed on the Web login page, you can get a new verification code.
  - Up to five users can concurrently log in to the device through the Web interface.
-

# 2 Setting IP Address

## Setting IP Address

### Creating a VLAN

Select **Network** > **VLAN** in the navigation tree. The system automatically selects the **VLAN** tab and enters the page as shown in [Figure 2-1](#).

**Figure 2-1** VLAN configuration page

<input type="checkbox"/>	ID	Description	Untagged Member	Tagged Member	Operation
<input type="checkbox"/>	1	VLAN 0001	GigabitEthernet1/0/1, WLAN-BSS1, WLAN-BSS2		

Click **Add** to enter the page for creating a VLAN, as shown in [Figure 2-2](#).

**Figure 2-2** Create a VLAN

VLAN ID:  \*(2-4094, Example: 3, 5-10)

Items marked with an asterisk(\*) are required

- Set VLAN ID 2.
- Click **Apply**.

### Setting IP Address

Select **Device** > **Interface** in the navigation tree to enter the page shown in [Figure 2-3](#). Click **Add** to enter the page for creating an interface, as shown in [Figure 2-4](#).



**Figure 2-3** Interface management page

The screenshot shows the 'Interface' management page. At the top, there is a search bar with 'Search Item: Name' and a 'Keywords:' input field, followed by a 'Search' button. Below this is a table with the following columns: Name, IP Address, Mask, Status, and Operation. The table contains three rows: 'GigabitEthernet1/0/1', 'NULL0', and 'Vlan-interface1'. The 'Vlan-interface1' row shows an IP Address of '192.168.0.50' and a Mask of '255.255.255.0'. Below the table is an 'Add' button.

Name	IP Address	Mask	Status	Operation
GigabitEthernet1/0/1			🟢	
NULL0			🟢	
Vlan-interface1	192.168.0.50	255.255.255.0	🟢	

[Add](#)

**Figure 2-4** Create an interface









The screenshot shows the 'Interface Creation' page. The 'Interface Name' is 'Vlan-interface 2' (with a note '(1-4094)'). The 'VID' field is empty. The 'MTU' and 'TCP MSS' fields are also empty. Under 'IP Config', 'Static Address' is selected. The 'IP Address' is '192.168.1.100' and the 'Mask' is '24 (255.255.255.0)'. There are two 'Secondary IP Address' fields, both with 'Mask' '24 (255.255.255.0)', and 'Add' and 'Remove' buttons. A box labeled '---Secondary IP Address List---' is empty. Under 'Unnumbered Interface', 'Vlan-interface1' is selected. Under 'IPv6 Config', 'None' is selected. The 'IPv6 Link Local Address' field is empty. At the bottom, there is a note 'Items marked with an asterisk(\*) are required' and 'Apply' and 'Back' buttons.

Interface Name: Vlan-interface 2 (1-4094)  
VID:   
MTU:   
TCP MSS:   
IP Config:  None  Static Address  DHCP  BOOTP  PPP Negotiate  Unnumbered  
IP Address: 192.168.1.100  
Mask: 24 (255.255.255.0)  
Secondary IP Address:  Add Remove  
Mask: 24 (255.255.255.0)  
Unnumbered Interface: Vlan-interface1  
IPv6 Config:  None  Auto  Manual  
IPv6 Link Local Address:   
Items marked with an asterisk(\*) are required  
[Apply](#) [Back](#)

- Choose Vlan-interface 2.
- Choose **Static Address**.
- Set the primary IP address **192.168.1.100**.
- Set the mask 24.
- Click **Apply**.

## Configuration verification

**Figure 2-5** View the IP address of VLAN 2

Name	IP Address	Mask	Status	Operation
GigabitEthernet1/0/1			+	 
NULL0			+	 
Vlan-interface1	192.168.0.50	255.255.255.0	+	 
Vlan-interface2	192.168.1.100	255.255.255.0	-	 

## Configuration guidelines

When satisfied with the configuration [Save Configuration to File](#) to ensure it is not lost when the Access Point restarts.


# 3 WLAN Access Configuration

## Wireless Service Configuration Example

### Network requirement

As shown in [Figure 3-1](#), it is required that the client access the wireless network by passing plain text authentication.

**Figure 3-1** WLAN service configuration



### Configuration procedure

- 1) Select a correct country/region code

Select **Advanced > Country/Region Code** from the navigation tree to enter the page for setting a country/region code, as shown in [Figure 3-2](#).

**Figure 3-2** Set a country/region code

The screenshot shows a configuration page titled 'Country/Region Code Setup'. At the top, there is a breadcrumb 'Country/Region Code'. Below it, the 'Country/Region Code' is set to 'US United States' in a dropdown menu. An 'Apply' button is located at the bottom right of the configuration area.

- 2) Configure a wireless service

# Create a wireless service.

Select **Wireless Service > Access Service** from the navigation tree, and click **New** to enter the page for creating a wireless service, as shown in [Figure 3-3](#):

**Figure 3-3** Create a wireless service

The screenshot shows a configuration page titled 'Access Service'. The 'Wireless Service Name' is set to 'service1' with a red asterisk and the text '\* Chars. (1-32)'. The 'Wireless Service Type' is set to 'clear' in a dropdown menu. Below the fields, a note states 'Items marked with an asterisk(\*) are required'. At the bottom, there are 'Apply' and 'Cancel' buttons.

- Set the service name as **service1**.
- Select the wireless service type **clear**.

- Click **Apply**.

3) Bind a radio to the wireless service and enable the wireless service

Select **Wireless Service > Access Service** from the navigation tree to enter the page for enabling wireless service, as shown in [Figure 3-4](#):

**Figure 3-4** Enable the wireless service

Access Service

Search Item: Wireless Service Keywords: Search

<input checked="" type="checkbox"/>	Wireless Service	Security Type	Wireless Service State	Operation
<input checked="" type="checkbox"/>	service1 <a href="#">[Bind]</a>	NONE	Disable	

New Enable Disable Delete

MAC AuthN List

- Click the **Bind** link in the **Wireless Service** column, select the target radio, and click **Bind**.
- Set the **service1** check box.
- Click **Enable**.

4) Enable 802.11n radio (By default, the 802.11n (2.4GHz) radio is enabled.)

Select **Radio > Radio** from the navigation tree to enter the **Radio** page, as shown in [Figure 3-5](#). Make sure that 802.11n (5GHz) radio is enabled.

**Figure 3-5** Enable 802.11n (5GHz) radio

Radio

Search Item: Radio Unit Keywords: Search

<input type="checkbox"/>	Radio Unit*	Radio Mode	Status	Operation
<input checked="" type="checkbox"/>	1	802.11n(5GHz)	Enable	
<input type="checkbox"/>	2	802.11n(2.4GHz)	Enable	

Enable Disable

### Configuration verification

- Select **Summary > Client** from the navigation tree to enter the page as shown in [Figure 3-6](#) to view the online clients.

**Figure 3-6** View the online clients

Client

Search Item: MAC Address Keywords: Search

<input type="checkbox"/>	MAC Address	Wireless Service	VLAN ID	IP Address	QoS Quality	Client Type	Client Rssi	Operation
<input type="checkbox"/>	0014-6c8a-43ff	service1	1	192.168.0.3	Y	802.11n(5GHz)		

Refresh Add to Blacklist Reset Statistic Disconnect



## Note

The IP addresses of clients obtained by the AP can be displayed only when ARP snooping is enabled. By default, ARP snooping is enabled.

- The client can be pinged successfully on the AP.

### Configuration guidelines

Note the following when configuring a wireless service:

- Select a correct country/region code.
- Make sure that radio is enabled.
- When satisfied with the configuration [Save Configuration to File](#) to ensure it is not lost when the Access Point restarts.


## Access Service Based VLAN Configuration Example

### Network requirements

As shown in [Figure 3-7](#), it is required to configure the AP to provide multiple wireless access services, that use different wireless security policies, and are bound to different VLANs to implement isolation between wireless access users. More specifically,

- Set up a wireless service named **research**, and configure it to use PSK authentication. Clients that access the WLAN are in VLAN 2.
- Set up a wireless service named **office**, and configure it to use clear text authentication. Clients that access the WLAN are in VLAN 3.

**Figure 3-7** Network diagram for access service-based VLAN configuration



### Configuration procedure

- 1) Select a correct country/region code

Select **Advanced > Country/Region Code** from the navigation tree to enter the page for setting a country/region code, as shown in [Figure 3-2](#).

- 2) Configure a wireless service named **research**.

# Create a wireless service.

Select **Wireless Service > Access Service** from the navigation tree, and click **Create** to enter the page for creating a wireless service.

- Configure the name of the wireless service as **research**.
- Select the wireless service type **crypto**.
- Click **Apply**.

# After the wireless service is created, the system is automatically navigated to the wireless service page, where you can perform the VLAN settings (before this operation, select **Network > VLAN** and create VLAN 2 first).

**Figure 3-8** Set the VLANs

Access Service		
Wireless Service	<input type="text" value="research"/>	
VLAN(Untagged)	<input type="text" value="2"/>	( 1-4094, Example: 3-5,10 )
Default VLAN	<input type="text" value="2"/>	( 1-4094 )
Delete VLAN	<input type="text" value="1"/>	( 1-4094, Example: 3-5,10 )
SSID Hide	<input type="text" value="Disable"/>	

- Type **2** in the **VLAN (Untagged)** text box.
- Type **2** in the **Default VLAN** text box.
- Type **1** in the **Delete VLAN** text box.



**Note**

For related configuration, refer to [PSK Authentication Configuration Example](#). You can strictly follow the configuration example to configure the PSK configuration.

3) Configure a wireless service named **office**.

# Create a wireless service.

- Configure the wireless service name as **office**.
- Select the wireless service type **clear**.
- Click **Apply**.

# After the wireless service is created, the system is automatically navigated to the wireless service page, where you can configure the VLANs (Create VLAN 3 in the **Network > VLAN** page).

**Figure 3-9** Set the VLANs

Access Service		
Wireless Service	<input type="text" value="office"/>	
VLAN(Untagged)	<input type="text" value="3"/>	( 1-4094, Example: 3-5,10 )
Default VLAN	<input type="text" value="3"/>	( 1-4094 )
Delete VLAN	<input type="text" value="1"/>	( 1-4094, Example: 3-5,10 )
SSID Hide	<input type="text" value="Disable"/>	

- Type **3** in the **VLAN (Untagged)** text box.
- Type **3** in the **Default VLAN** text box.
- Type **1** in the **Delete VLAN** text box.

- Click **Apply**.

# Bind the corresponding radio to wireless services **office** and **research** respectively, enable the wireless services **office** and **research**, and enable the radios.

4) Verify the configuration

Select **Summary > Client** from the navigation tree, and enter the page shown in [Figure 3-10](#) to view the online clients.

**Figure 3-10** View the online clients

Client								
Search Item: <input type="text" value="MAC Address"/>		Keywords: <input type="text"/>		<input type="button" value="Search"/>				
<input type="checkbox"/>	MAC Address	Wireless Service	VLAN ID	IP Address	QoS Quality	Client Type	Client Rssi	Operation
<input type="checkbox"/>	0014-6c8a-43ff	office	3	1.1.1.1	Y	802.11n(2.4GHz)		
<input type="checkbox"/>	0040-96b3-8a77	research	2	2.2.2.1	Y	802.11n(2.4GHz)		

On this page, you can see that client 2, which accesses the SSID **office**, is in VLAN 3, while client 1, which accesses the SSID **research**, is in VLAN 2. Because the two clients are in different VLANs, they cannot access each other.

### Configuration guidelines


When satisfied with the configuration [Save Configuration to File](#) to ensure it is not lost when the Access Point restarts.

## PSK Authentication Configuration Example

### Network requirements

As shown in [Figure 3-11](#), it is required that the client access the wireless network by passing PSK authentication. The PSK key configuration on the client is the same as that on the AP, that is, **12345678**.

**Figure 3-11** Network diagram for PSK authentication configuration



### Configuration procedure

1) Select a correct country/region code

Select **Advanced > Country/Region Code** from the navigation tree to enter the page for setting a country/region code, as shown in [Figure 3-2](#).

2) Configure a wireless service

# Create a wireless service.

Select **Wireless Service > Access Service** from the navigation tree, and click **New** to enter the page for creating a wireless service, as shown in [Figure 3-12](#):

**Figure 3-12** Create a wireless service

Access Service

Wireless Service Name  \* Chars. (1-32)

Wireless Service Type

Items marked with an asterisk(\*) are required

Apply Cancel

- Set the service name to **psk**.
- Select the wireless service type **crypto**.
- Click **Apply**.

3) Configure the wireless service

After you create a wireless service, you will enter the wireless service configuration page. You need to perform security setup when configuring PSK authentication, as shown in [Figure 3-13](#):

**Figure 3-13** Security setup

+ Advance Setup

- Security Setup

Authentication Type

Cipher Suite  Security IE

Encryption

WEP

Key ID

Key Length

WEP Key

- Port Security

Port Set

Port Mode

Max User  (1-1024)

PSK

Preshared Key   (8 - 63 Chars.)

Apply Cancel


- Select the **Open-System** from the **Authentication Type** drop-down list.
- Select **Cipher Suite** check box, select **CCMP and TKIP** (select an encryption type as needed), and then select **WPA** from the **Security IE** drop-down list.
- Select the **Port Set** check box, and select **psk** from the **Port Mode** drop-down list.
- Select **pass-phrase** from the **Preshared Key** drop-down list, and type key ID **12345678**.
- Click **Apply**.

4) Bind the radio to the wireless service, and enable the wireless service

Select **Wireless Service > Access Service** from the navigation tree to enter the page for enabling a wireless service, as shown in [Figure 3-14](#):



**Figure 3-14** Bind the radio to and enable the wireless service




- Click the **Bind** link in the **Wireless Service** column, select the target radio, and click **Bind**.
  - Select the **psk** check box.
  - Click **Enable**.
- 5) Enable 802.11n (2.4GHz) radio (By default, 802.11n (2.4GHz) radio is enabled. Therefore, this step is optional.)

Select **Radio > Radio** from the navigation tree to enter the **Radio** page. Make sure that 802.11n (2.4GHz) radio is enabled.

**Configuration verification**

The same PSK pre-shared key is configured on the client. The client can successfully associate with the AP (as shown in [Figure 3-15](#)) and can access the WLAN network.

**Figure 3-15** The client associates with the AP



**Configuration guidelines**


When satisfied with the configuration [Save Configuration to File](#) to ensure it is not lost when the Access Point restarts.

**Local MAC Authentication Configuration Example**

**Network requirements**

As shown in [Figure 3-16](#), configure the fat AP to perform MAC authentication on the client.

**Figure 3-16** Network diagram for local MAC authentication configuration



### Configuration procedure

- 1) Select a correct country/region code

Select **Advanced > Country/Region Code** from the navigation tree to enter the page for setting a country/region code, as shown in [Figure 3-2](#).

- 2) Configure a wireless service

# Create a wireless service.

Select **Wireless Service > Access Service** from the navigation tree, and click **New** to enter the page for creating a wireless service, as shown in [Figure 3-17](#):

**Figure 3-17** Create a wireless service

Access Service

Wireless Service Name  \* Chars. (1-32)

Wireless Service Type  ▼

Items marked with an asterisk(\*) are required

- Set the service name to **mac-auth**.
- Select the wireless service type **clear**.
- Click **Apply**.

- 3) Configure the wireless service

After you have created a wireless service, you will enter the wireless service configuration page. You need to perform security setup when configuring MAC authentication, as shown in [Figure 3-18](#):

**Figure 3-18** Security setup

Security Setup

Authentication Type: **Open-System** (dropdown)

Cipher Suite: (dropdown) Security IE: (dropdown)

Encryption

WEP: (dropdown)

Key ID: (dropdown)

Key Length: (dropdown) WEP Key: (text input)

Port Security

Port Set

Port Mode: **mac-authentication** (dropdown)

Max User: (text input) (1-1024)

MAC Authentication

Domain: **system** (dropdown)

Note: Before enabling "MAC Authentication", enter the "MAC Setup" page to configure MAC addresses of wireless clients from which access is permitted.

Apply Cancel

- Select the **Open-System** from the **Authentication Type** drop-down list.
- Select the **Port Set** check box, and select **mac-authentication** from the **Port Mode** drop-down list.
- Select **MAC Authentication** check box, and select **system** from the **Domain** drop-down list (you can select **Authentication > AAA** from the navigation tree, click the **Domain Setup** tab, and create a domain in the **Domain Name** drop-down combo box).
- Click **Apply**.

4) Bind the radio to the wireless service, and enable the wireless service

Select **Wireless Service > Access Service** from the navigation tree to enter the page for enabling a wireless service, as shown in [Figure 3-19](#):

**Figure 3-19** Bind the radio to and enable the wireless service

Access Service

Search Item: **Wireless Service** (dropdown) Keywords: (text input) Search

<input type="checkbox"/>	Wireless Service	Security Type	Wireless Service State	Operation
<input type="checkbox"/>	mac-auth[Bind]	MIX	Disable	

New Enable Disable Delete


MAC AuthN List

- Click the **Bind** link in the **Wireless Service** column, select the target radio, and click **Bind**.
- Select the **mac-auth** check box.
- Click **Enable**.

5) Configure a MAC authentication list

Select **Wireless Service > Access Service** from the navigation tree, and click **MAC Authentication List** to enter the page for configuring a MAC authentication list, as shown in [Figure 3-20](#):

**Figure 3-20** Add a MAC authentication list



Access Service

MAC Address:  (Example: 00-fe-12-34-56-78)

Search Item:  Keywords:

<input type="checkbox"/>	MAC Address	Operation
--------------------------	-------------	-----------

Demo : Modified this page, work on all of MAC addresses of wireless clients from which access is permitted.

- Add a local user in the **MAC Address** box. **00-14-6c-8a-43-ff** is used in this example.
- Click **Add**.

6) Enable 802.11n (2.4GHz) radio (By default, 802.11n (2.4GHZ) radio is enabled. Therefore, this step is optional. )

Select **Radio > Radio** from the navigation tree to enter the **Radio** page. Make sure that 802.11n (2.4GHz) is enabled.

### Configuration verification

- If the MAC address of the client is in the MAC authentication list, the client can pass authentication and access the WLAN network.
- The client can be pinged on the AP.

### Configuration guidelines

When satisfied with the configuration [Save Configuration to File](#) to ensure it is not lost when the Access Point restarts.


## Remote MAC Authentication Configuration Example

### Network requirements

It is required to perform remote MAC authentication on the client. More specifically,

- Use the intelligent management center (iMC) as the RADIUS server for authentication, authorization, and accounting (AAA). On the RADIUS server, configure the client's username and password as the MAC address of the client and the shared key as **expert**. The IP address of the RADIUS server is 10.18.1.88.
- The IP address of the AP is 10.18.1.1. On the AP, configure the shared key for communication with the RADIUS server as **expert**, and configure the AP to remove the domain name of a username before sending it to the RADIUS server.

**Figure 3-21** Remote MAC authentication



### Configuration procedure

- 1) Configure the IP address of the fat AP

In the **Network > VLAN** page, create a VLAN on the fat AP, and configure the VLAN interface in the **Device > Interface Management** page.

- 2) Configure a RADIUS scheme

# Configure the RADIUS authentication server.

From the navigation tree, select **Authentication > RADIUS**. The RADIUS server configuration page appears. Perform the following configuration, as shown in [Figure 3-22](#).

**Figure 3-22** Configure the RADIUS authentication server

RADIUS Server	RADIUS Setup
Server Type:	Authentication Server <input type="button" value="v"/>
Primary Server IP:	10.18.1.88 *
Primary Server UDP Port:	1812 *(1-65535)
Primary Server Status:	active <input type="button" value="v"/>
Secondary Server IP:	0.0.0.0 *
Secondary Server UDP Port:	1812 *(1-65535)
Secondary Server Status:	block <input type="button" value="v"/>

Items marked with an asterisk(\*) are required

- Select **Authentication Server** as the server type.
- Enter **10.18.1.88** as the IP address of the primary authentication server
- Enter **1812** as the UDP port of the primary authentication server.
- Select **active** as the primary server status.
- Click **Apply**.

# Configure the RADIUS accounting server, as shown in [Figure 3-23](#).

**Figure 3-23** Configure the RADIUS accounting server

RADIUS Server	RADIUS Setup
Server Type:	Accounting Server <input type="button" value="v"/>
Primary Server IP:	10.18.1.88 *
Primary Server UDP Port:	1813 *(1-65535)
Primary Server Status:	active <input type="button" value="v"/>
Secondary Server IP:	0.0.0.0 *
Secondary Server UDP Port:	1813 *(1-65535)
Secondary Server Status:	block <input type="button" value="v"/>

Items marked with an asterisk(\*) are required

- Select **Accounting Server** as the server type.
- Enter **10.18.1.88** as the IP address of the primary accounting server.
- Enter **1813** as the UDP port of the primary accounting server.
- Select **active** as the primary server status.
- Click **Apply**.

# Configure the parameters for communication between the AP and the RADIUS servers.

- Select the **RADIUS Setup** tab and configure the parameters, as shown in [Figure 3-24](#).

**Figure 3-24** Configure RADIUS parameters

RADIUS Server	RADIUS Setup
Server Type:	extended <input type="button" value="v"/>
<input checked="" type="checkbox"/> Authentication Server Shared Key:	***** (1-64 Chars.)
Confirm Authentication Shared Key:	*****
<input checked="" type="checkbox"/> Accounting Server Shared Key:	***** (1-64 Chars.)
Confirm Accounting Shared Key:	*****
NAS-IP:	<input type="text"/>
Timeout Interval:	3 *seconds(1-10)
Timeout Retransmission Times:	3 *(1-20)
Realtime-Accounting Interval:	12 *minutes(0-60, Must be a multiple of 3)
Realtime-Accounting Packet Retransmission Times:	5 *(1-255)
Stop-Accounting Buffer:	enable <input type="button" value="v"/>
Stop-Accounting Packet Retransmission Times:	500 *(10-65535)
Quiet Interval:	5 *minutes(1-255)
Username Format:	without-domain <input type="button" value="v"/>
Unit of Data Flows:	byte <input type="button" value="v"/>
Unit of Packets:	packet <input type="button" value="v"/>

Items marked with an asterisk(\*) are required

- Select **extended** as the server type.

- Select the **Authentication Server Shared Key** check box and enter **expert** in the text box.
- Enter **expert** in the **Confirm Authentication Shared Key** text box.
- Select the **Accounting Server Shared Key** check box and enter **expert** in the text box.
- Enter **expert** in the **Confirm Accounting Shared Key** text box.
- Select **without-domain** for **Username Format**.
- Click **Apply**

3) Configure AAA

# Create an ISP domain.

- From the navigation tree, select **Authentication > AAA**. The domain setup page appears. In this example, the default domain **system** is used (you can create and configure a new ISP domain as needed).

# Configure the AAA authentication method for the ISP domain.

- Select the **Authentication** tab, as shown in [Figure 3-25](#).

**Figure 3-25** Configure the AAA authentication method for the ISP domain

Domain Setup | **Authentication** | Authorization | Accounting

Authentication Configuration of AAA

Select an ISP domain: system

<input checked="" type="checkbox"/> Default AuthN	RADIUS	Name	system	Secondary Method	
<input type="checkbox"/> LAN-access AuthN		Name		Secondary Method	
<input type="checkbox"/> Login AuthN		Name		Secondary Method	
<input type="checkbox"/> PPP AuthN		Name		Secondary Method	
<input type="checkbox"/> Portal AuthN		Name		Secondary Method	

Apply

Perform the following configuration, as shown in [Figure 3-25](#).

- Select the ISP domain name **system**.
- Select the **Default AuthN** checkbox and then select **RADIUS** as the authentication mode.
- Select **system** from the **Name** drop-down list to use it as the authentication scheme.
- Click **Apply**. A configuration progress dialog box appears.
- After the configuration process is complete, click **Close**.

# Configure the AAA authorization method for the ISP domain.

- Select the **Authorization** tab, as shown in [Figure 3-26](#).

**Figure 3-26** Configure the AAA authorization method for the ISP domain

Domain Setup Authentication **Authorization** Accounting

Authorization Configuration of AAA

Select an ISP domain system

<input checked="" type="checkbox"/> Default AuthZ	RADIUS	Name	system	Secondary Method	
<input type="checkbox"/> LAN-access AuthZ		Name		Secondary Method	
<input type="checkbox"/> Login AuthZ		Name		Secondary Method	
<input type="checkbox"/> PPP AuthZ		Name		Secondary Method	
<input type="checkbox"/> Portal AuthZ		Name		Secondary Method	
<input type="checkbox"/> Command AuthZ		Name		Secondary Method	

Apply

Perform the following configuration, as shown in [Figure 3-26](#).

- Select the domain name **system**.
- Select the **Default AuthZ** checkbox and then select **RADIUS** as the authorization mode.
- Select **system** from the **Name** drop-down list to use it as the authorization scheme.
- Click **Apply**. A configuration progress dialog box appears.
- After the configuration process is complete, click **Close**.

# Configure the AAA accounting method for the ISP domain, and enable **Accounting Optional**.

- Select the **Accounting** tab, as shown in [Figure 3-27](#).

**Figure 3-27** Configure the AAA accounting method for the ISP domain

Domain Setup Authentication Authorization **Accounting**

Accounting Configuration of AAA

Select an ISP domain system

<input checked="" type="checkbox"/> Accounting Optional	Enable				
<input checked="" type="checkbox"/> Default Accounting	RADIUS	Name	system	Secondary Method	
<input type="checkbox"/> LAN-access Accounting		Name		Secondary Method	
<input type="checkbox"/> Login Accounting		Name		Secondary Method	
<input type="checkbox"/> PPP Accounting		Name		Secondary Method	
<input type="checkbox"/> Portal Accounting		Name		Secondary Method	

Apply

Perform the following configuration, as shown in [Figure 3-27](#).

- Select the domain name **system**.
  - Select the **Accounting Optional** checkbox and then select **Enable**.
  - Select the **Default Accounting** checkbox and then select **RADIUS** as the accounting mode.
  - Select **system** from the **Name** drop-down list to use it as the accounting scheme.
  - Click **Apply**. A configuration progress dialog box appears.
  - After the configuration process is complete, click **Close**.
- 4) Configure wireless service



# Create a wireless service.

Select **Wireless Service > Access Service** from the navigation tree, and click **New** to enter the page for creating a wireless service, as shown in [Figure 3-28](#):

**Figure 3-28** Create a wireless service

Access Service

Wireless Service Name  \* Chars. (1-32)

Wireless Service Type

Items marked with an asterisk(\*) are required

Apply Cancel

- Set the wireless service name as **mac-auth**.
- Select the wireless service type **clear**.
- Click **Apply**.

5) Configure MAC authentication

After you create a wireless service, you will enter the wireless service configuration page. Then you can configure MAC authentication on the **Security Setup** area, as shown in [Figure 3-29](#):

**Figure 3-29** Security setup

+ Advance Setup

- Security Setup

Authentication Type

Cipher Suite  Security IE

Encryption

WEP

Key ID

Key Length  WEP Key

- Port Security

Port Set

Port Mode

Max User  (1-1024)

MAC Authentication

Domain

Note: Before enabling "MAC Authentication", enter the "MAC Setup" page to configure MAC addresses of wireless clients from which access is permitted.


Apply Cancel

- Select **Open-System** from the **Authentication Type** drop-down list.
- Select the **Port Set** check box, and select **mac-authentication** from the **Port Mode** drop-down list.
- Select **MAC Authentication** check box, and select **system** from the **Domain** drop-down list.
- Click **Apply**.

6) Bind the radio to the wireless service and enable the wireless service

Select **Wireless Service > Access Service** from the navigation tree to enter the page as shown in the following figure.

**Figure 3-30** Bind the radio to the wireless service and enable the wireless service



- Click the **Bind** link in the **Wireless Service** column, select the target radio, and click **Bind**.
  - Select the **mac-auth** check box.
  - Click **Enable**.
- 7) Enable 802.11g radio (By default, the 802.11g radio is enabled. Therefore, this step is optional. )  
Select **Radio > Radio** from the navigation tree to enter the **Radio** page. Make sure that 802.11g is enabled.
- 8) Configure the RADIUS server (iMC)

---

 **Note**

The following takes the iMC (iMC PLAT 3.20-R2602 and iMC UAM 3.60-E6102) as an example to illustrate the basic configuration of the RADIUS server.

---

# Add an access device.

Log in to the iMC management platform. Select the **Service** tab, and then select **Access Service > Access Device** from the navigation tree to enter the access device configuration page. Click **Add** on the page to enter the configuration page as shown in [Figure 3-31](#):

- Input **expert** as the **Shared Key**.
- Add ports **1812**, and **1813** for **Authentication Port** and **Accounting Port** respectively.
- Select **LAN Access Service** for **Service Type**.
- Select **H3C** for **Access Device Type**.
- Select or manually add the access device (the AP) with the IP address 10.18.1.1.

**Figure 3-31** Add access device

Service >> Access Service >> Access Device >> Add Access Device Help

**Access Configuration**

\* Shared Key:       \* Accounting Port:

\* Authentication Port:       \* Access Device Type:

\* Service Type:

---

**Device List**

Total Items: 0.

Device Name	Device IP	Device Model	Delete

---

**Existing Access Device List**

Total Items: 1.

Device Name	Device IP	Device Model
	10.18.1.1	

# Add service.

Select the **Service** tab, and then select **Access Service > Service Configuration** from the navigation tree to enter the add service page. Then click **Add** on the page to enter the following configuration page. Set the service name as **mac**, and keep the default values for other parameters.

**Figure 3-32** Add service

Service >> Access Service >> Service Configuration >> Add Service Configuration Help

**Add Service Configuration**

**Basic Information**

\* Service Name:       Service Suffix:

\* Service Group:

\* Security Policy:

Description:

LDAP Priority:        Available ?

# Add account.

Select the **User** tab, and then select **User > All Access Users** from the navigation tree to enter the user page. Then, click **Add** on the page to enter the page as shown in [Figure 3-33](#).

- Enter username **00146c8a43ff**.
- Set the account name and password both as **00146c8a43ff**.
- Select the service **mac**.

**Figure 3-33 Add account**

User >> Add Access User ? Help

---

**Access account**

**Access Information**

\* userName: 00146c8a43ff Select Add User

\* Account Name: 00146c8a43ff  Fast Access User

\* Password: ..... \* Confirm Password: .....

Allow User to Modify Password  Enable User Password Strategy  Modify Password at Next Login

Expiry Date:  ?

Max. Idle Time:  Minutes Max. Concurrent Limit:

Login Message:

**Access Service**

	Service Name	Service Suffix	Security Policy	User IP Address
<input checked="" type="checkbox"/>	mac			

**Configuration verification**

During authentication, the client does not need to input the username or password. After the client passes MAC authentication, the client can associate with the AP and access the WLAN. You can view the online clients by selecting **Summary > Client**.

**Configuration guidelines**

When satisfied with the configuration [Save Configuration to File](#) to ensure it is not lost when the Access Point restarts.


**Remote 802.1X Authentication Configuration Example**

**Network requirements**

It is required to perform remote 802.1X authentication on the client. More specifically,

- Use the CAMS or iMC as a RADIUS server for AAA. On the RADIUS server, configure the client's username as **user**, password as **dot1x**, and shared key as **expert**. The IP address of the RADIUS server is 10.18.1.88.
- On the AP, configure the shared key as **expert**, and configure the AP to remove the domain name of a username before sending it to the RADIUS server. The IP address of the AP is 10.18.1.1.

**Figure 3-34 Remote 802.1X authentication**



**Configuration procedure**

- 1) Configure the IP address of the fat AP

In the **Network > VLAN** page, create a VLAN on the fat AP, and in the **Device > Interface Management** page, configure the VLAN interface.

2) Configure a RADIUS scheme

# Configure the RADIUS authentication server.

From the navigation tree, select **Authentication > RADIUS**. The RADIUS server configuration page appears.

**Figure 3-35** Configure the RADIUS authentication server

The screenshot shows the 'RADIUS Setup' configuration page. The 'Server Type' is set to 'Authentication Server'. The 'Primary Server IP' is 10.18.1.88, 'Primary Server UDP Port' is 1812, and 'Primary Server Status' is 'active'. The 'Secondary Server IP' is 0.0.0.0, 'Secondary Server UDP Port' is 1812, and 'Secondary Server Status' is 'block'. A note at the bottom states 'Items marked with an asterisk(\*) are required'. An 'Apply' button is located at the bottom right.

Field	Value	Required
Server Type	Authentication Server	
Primary Server IP	10.18.1.88	*
Primary Server UDP Port	1812	*(1-65535)
Primary Server Status	active	
Secondary Server IP	0.0.0.0	*
Secondary Server UDP Port	1812	*(1-65535)
Secondary Server Status	block	

Items marked with an asterisk(\*) are required

Apply

Perform the following configuration, as shown in [Figure 3-35](#).

- Select **Authentication Server** as the server type.
- Enter **10.18.1.88** as the IP address of the primary authentication server
- Enter **1812** as the UDP port of the primary authentication server.
- Select **active** as the primary server status.
- Click **Apply**.

# Configure the RADIUS accounting server.

**Figure 3-36** Configure the RADIUS accounting server

The screenshot shows the 'RADIUS Setup' configuration page. The 'Server Type' is set to 'Accounting Server'. The 'Primary Server IP' is 10.18.1.88, 'Primary Server UDP Port' is 1813, and 'Primary Server Status' is 'active'. The 'Secondary Server IP' is 0.0.0.0, 'Secondary Server UDP Port' is 1813, and 'Secondary Server Status' is 'block'. A note at the bottom states 'Items marked with an asterisk(\*) are required'. An 'Apply' button is located at the bottom right.

Field	Value	Required
Server Type	Accounting Server	
Primary Server IP	10.18.1.88	*
Primary Server UDP Port	1813	*(1-65535)
Primary Server Status	active	
Secondary Server IP	0.0.0.0	*
Secondary Server UDP Port	1813	*(1-65535)
Secondary Server Status	block	

Items marked with an asterisk(\*) are required

Apply

Perform the following configuration, as shown in [Figure 3-36](#).

- Select **Accounting Server** as the server type.
- Enter **10.18.1.88** as the IP address of the primary accounting server.
- Enter **1813** as the UDP port of the primary accounting server.
- Select **active** as the primary server status.
- Click **Apply**.

# Configure the parameters for communication between the AP and the RADIUS servers.

- Select the **RADIUS Setup** tab and configure the parameters, as shown in [Figure 3-37](#).

**Figure 3-37** Configure RADIUS parameters

RADIUS Server		RADIUS Setup	
Server Type:	<input type="text" value="extended"/>		
<input checked="" type="checkbox"/> Authentication Server Shared Key:	<input type="text" value="....."/>	(1-64 Chars.)	
Confirm Authentication Shared Key:	<input type="text" value="....."/>		
<input checked="" type="checkbox"/> Accounting Server Shared Key:	<input type="text" value="....."/>	(1-64 Chars.)	
Confirm Accounting Shared Key:	<input type="text" value="....."/>		
NAS-IP:	<input type="text"/>		
Timeout Interval:	<input type="text" value="3"/>	*seconds(1-10)	
Timeout Retransmission Times:	<input type="text" value="3"/>	*(1-20)	
Realtime-Accounting Interval:	<input type="text" value="12"/>	*minutes(0-60, Must be a multiple of 3)	
Realtime-Accounting Packet Retransmission Times:	<input type="text" value="5"/>	*(1-255)	
Stop-Accounting Buffer:	<input type="text" value="enable"/>		
Stop-Accounting Packet Retransmission Times:	<input type="text" value="500"/>	*(10-65535)	
Quiet Interval:	<input type="text" value="5"/>	*minutes(1-255)	
Username Format:	<input type="text" value="without-domain"/>		
Unit of Data Flows:	<input type="text" value="byte"/>		
Unit of Packets:	<input type="text" value="packet"/>		

Items marked with an asterisk(\*) are required

- Select **extended** as the server type.
- Select the **Authentication Server Shared Key** check box and enter **expert** in the text box.
- Enter **expert** in the **Confirm Authentication Shared Key** text box.
- Select the **Accounting Server Shared Key** check box and enter **expert** in the text box.
- Enter **expert** in the **Confirm Accounting Shared Key** text box.
- Select **without-domain** for **Username Format**.
- Click **Apply**.

3) Configure AAA

# Create an ISP domain.

- From the navigation tree, select **Authentication > AAA**. The domain setup page appears. In this example, the default domain **system** is used (you can create and configure a new ISP domain as needed).

# Configure the AAA authentication method for the ISP domain.

- Select the **Authentication** tab, as shown in [Figure 3-38](#).

**Figure 3-38** Configure the AAA authentication method for the ISP domain

Domain Setup | **Authentication** | Authorization | Accounting

Authentication Configuration of AAA

Select an ISP domain: system

<input checked="" type="checkbox"/> Default AuthN	RADIUS	Name	system	Secondary Method	
<input type="checkbox"/> LAN-access AuthN		Name		Secondary Method	
<input type="checkbox"/> Login AuthN		Name		Secondary Method	
<input type="checkbox"/> PPP AuthN		Name		Secondary Method	
<input type="checkbox"/> Portal AuthN		Name		Secondary Method	

Apply

Perform the following configuration, as shown in [Figure 3-38](#).

- Select the ISP domain name **system**.
- Select the **Default AuthN** checkbox and then select **RADIUS** as the authentication mode.
- Select **system** from the **Name** drop-down list to use it as the authentication scheme.
- Click **Apply**. A configuration progress dialog box appears.
- After the configuration process is complete, click **Close**.

# Configure the AAA authorization method for the ISP domain.

- Select the **Authorization** tab, as shown in [Figure 3-39](#).

**Figure 3-39** Configure the AAA authorization method for the ISP domain

Domain Setup | Authentication | **Authorization** | Accounting

Authorization Configuration of AAA

Select an ISP domain: system

<input checked="" type="checkbox"/> Default AuthZ	RADIUS	Name	system	Secondary Method	
<input type="checkbox"/> LAN-access AuthZ		Name		Secondary Method	
<input type="checkbox"/> Login AuthZ		Name		Secondary Method	
<input type="checkbox"/> PPP AuthZ		Name		Secondary Method	
<input type="checkbox"/> Portal AuthZ		Name		Secondary Method	
<input type="checkbox"/> Command AuthZ		Name		Secondary Method	

Apply

Perform the following configuration, as shown in [Figure 3-39](#).

- Select the domain name **system**.
- Select the **Default AuthZ** checkbox and then select **RADIUS** as the authorization mode.
- Select **system** from the **Name** drop-down list to use it as the authorization scheme.
- Click **Apply**. A configuration progress dialog box appears.
- After the configuration process is complete, click **Close**.

# Configure the AAA accounting method for the ISP domain, and enable **Accounting Optional**.

- Select the **Accounting** tab, as shown in [Figure 3-40](#).

**Figure 3-40** Configure the AAA accounting method for the ISP domain

Domain Setup Authentication Authorization Accounting

Accounting Configuration of AAA

Select an ISP domain system

Accounting Optional Enable

Default Accounting RADIUS Name system Secondary Method

LAN-access Accounting Name Secondary Method

Login Accounting Name Secondary Method

PPP Accounting Name Secondary Method

Portal Accounting Name Secondary Method

Apply

Perform the following configuration, as shown in [Figure 3-40](#).

- Select the domain name **system**.
- Select the **Accounting Optional** checkbox and then select **Enable**.
- Select the **Default Accounting** checkbox and then select **RADIUS** as the accounting mode.
- Select **system** from the **Name** drop-down list to use it as the accounting scheme.
- Click **Apply**. A configuration progress dialog box appears.
- After the configuration process is complete, click **Close**.

4) Configure wireless service

# Create a wireless service.

Select **Wireless Service** > **Access Service** from the navigation tree, and click **New** to enter the page for creating a wireless service, as shown in [Figure 3-41](#):

**Figure 3-41** Create a wireless service

Access Service

Wireless Service Name dot1x \* Chars. (1-32)

Wireless Service Type crypto

Items marked with an asterisk(\*) are required

Apply Cancel

- Set the service name as **dot1x**.
- Select the wireless service type **crypto**.
- Click **Apply**.

5) Configure 802.1X authentication

After you create a wireless service, you will enter the wireless service configuration page. Then you can configure 802.1X authentication on the **Security Setup** area, as shown in [Figure 3-42](#):



**Figure 3-42 Security setup**

- Select **Open-System** from the **Authentication Type** drop-down list.
  - Select the **Cipher Suite** check box, select **CCMP** from the **Cipher Suite** drop-down list, and select **WPA2** from the **Security IE** drop-down list.
  - Select the **Port Set** check box, and select **userlogin-secure-ext** from the **Port Mode** drop-down list.
  - Select **system** from the **Mandatory Domain** drop-down list.
  - Select **EAP** from the **Authentication Method** drop-down list.
  - You are recommended to disable **Handshake** and **Multicast Trigger**.
  - Click **Apply**.
- 6) Bind the radio to the wireless service and enable the wireless service

Select **Wireless Service > Access Service** from the navigation tree to enter the page as shown in the following figure.

**Figure 3-43 Bind the radio to the wireless service and enable the wireless service**

Wireless Service	Security Type	Wireless Service State	Operation
<input type="checkbox"/> dot1x[Bind]	MIX	Disable	

- Click the **Bind** link in the **Wireless Service** column, select the target radio, and click **Bind**.
  - Select the **dot1x** check box.
  - Click **Enable**.
- 7) Enable 802.11g radio (By default, the 802.11g radio is enabled. Therefore, this step is optional. )

Select **Radio > Radio** from the navigation tree to enter the **Radio** page. Make sure that 802.11g is enabled.

8) Configure the RADIUS server (iMC)



#### Note

The following takes the iMC (iMC PLAT 3.20-R2602 and iMC UAM 3.60-E6102) as an example to illustrate the basic configuration of the RADIUS server.

# Add an access device.

Log in to the iMC management platform. Select the **Service** tab, and then select **Access Service > Access Device** from the navigation tree to enter the access device configuration page. Click **Add** on the page to enter the configuration page as shown in [Figure 3-44](#):

- Input **expert** as the **Shared Key**.
- Add ports **1812**, and **1813** for **Authentication Port** and **Accounting Port** respectively.
- Select **LAN Access Service** for **Service Type**.
- Select **H3C** for **Access Device Type**.
- Select or manually add the access device (the AP) with the IP address 10.18.1.1.

**Figure 3-44** Add access device

Service >> Access Service >> Access Device >> Add Access Device ? Help

**Access Configuration**

* Shared Key	<input type="text" value="expert"/>	* Accounting Port	<input type="text" value="1813"/>
* Authentication Port	<input type="text" value="1812"/>	* Access Device Type	<input type="text" value="H3C"/>
* Service Type	<input type="text" value="LAN Access Service"/>		

**Device List**

Select Add Manually Clear All

Total Items: 0.

Device Name	Device IP	Device Model	Delete
-------------	-----------	--------------	--------

**Existing Access Device List**

Total Items: 1.

Device Name	Device IP	Device Model
	10.18.1.1	


OK Cancel

# Add service.

Select the **Service** tab, and then select **Access Service > Service Configuration** from the navigation tree to enter the add service page. Then click **Add** on the page to enter the following configuration page.

- Set the service name as **dot1x**.
- Set the **Certificate Type** to **EAP-PEAP AuthN** and the **Certificate Sub Type** to **MS-CHAPV2 AuthN**.

**Figure 3-45 Add service**

 [Service](#) >> [Access Service](#) >> [Service Configuration](#) >> [Add Service Configuration](#) [Help](#)

**Add Service Configuration**

**Basic Information**

\* Service Name:  Service Suffix:

\* Service Group:

\* Security Policy:

Description:

LDAP Priority:   Available [?](#)

**Authorization Information**

\* Access Period:  \* Disable Binding in:

Downstream Rate:  Kbps Upstream Rate:  Kbps

Priority:   RSA enable

Certificate AuthN:  Disable Certificate AuthN  EAP AuthN  WAPI AuthN

Certificate Type:  Certificate Sub-Type:

\* Allocate IP:

Deploy VLAN:

Deploy User Group:  [?](#)


Deploy ACL

# Add account.

Select the **User** tab, and then select **User > All Access Users** from the navigation tree to enter the user page. Then, click **Add** on the page to enter the page shown in [Figure 3-46](#).

- Enter username **user**.
- Set the account name as **user** and password as **dot1x**.
- Select the service **dot1x**.

**Figure 3-46 Add account**

 [User](#) >> [Add Access User](#) [Help](#)

**Access account**

**Access Information**

\* userName:

\* Account Name:   Fast Access User

\* Password:  \* Confirm Password:

Allow User to Modify Password  Enable User Password Strategy  Modify Password at Next Login

Expiry Date:  [?](#)

Max. Idle Time:  Minutes Max. Concurrent Limit:

Login Message:

**Access Service**

	Service Name	Service Suffix	Security Policy	User IP Address
<input type="checkbox"/>	dot1x			

**Configuration verification**

- After inputting username **user** and password **dot1x** in the popup dialog box, the client can associate with the AP and access the WLAN.

- You can view the online clients by selecting **Summary > Client**.

### Configuration guidelines


When satisfied with the configuration [Save Configuration to File](#) to ensure it is not lost when the Access Point restarts.

## 802.11n Configuration Example

### Network requirements

As shown in [Figure 3-47](#), configure the AP supporting 802.11n to provide wireless access for 802.11n clients.

**Figure 3-47** Network diagram for wireless service configuration



### Configuration procedure

- 1) Select a correct country/region code

Select **Advanced > Country/Region Code** from the navigation tree to enter the page for setting a country/region code, as shown in [Figure 3-2](#).

- 2) Configure a wireless service

# Create a wireless service.

Select **Wireless Service > Access Service** from the navigation tree, and click **New** to enter the page for creating a wireless service, as shown in [Figure 3-48](#):

**Figure 3-48** Create a wireless service

The screenshot shows the 'Access Service' configuration page. The 'Wireless Service Name' field contains '11nservice' and is marked with an asterisk (\*) and 'Chars. (1-32)'. The 'Wireless Service Type' dropdown menu is set to 'clear'. Below the form, there is a note: 'Items marked with an asterisk(\*) are required'. At the bottom right, there are 'Apply' and 'Cancel' buttons.

- Set the service name to **11nservice**.
- Select the wireless service type **clear**.
- Click **Apply**.

- 3) Bind the radio to the wireless service and enable the wireless service

Select **Wireless Service > Access Service** from the navigation tree to enter the pages as shown in [Figure 3-49](#):

**Figure 3-49** Bind the radio to the wireless service and enable the wireless service

Access Service

Search Item:  Keywords:  Search

<input type="checkbox"/>	Wireless Service	Security Type	Wireless Service State	Operation
<input type="checkbox"/>	11nservice[Bind]	NONE	Disable	

New Enable Disable Delete

MAC AuthN List

- Click the **Bind** link in the **Wireless Service** column, select the target radio, and click **Bind**.
  - Select the **11nservice** check box.
  - Click **Enable**.
- 4) Enable 802.11n (2.4GHZ) radio (By default, 802.11n (2.4GHZ) radio is enabled. Therefore, this step is optional. )

Select **Radio > Radio** from the navigation tree to enter the **Radio** page. Make sure that 802.11n (2.4GHZ) is enabled.

**Figure 3-50** Enable the radio

Radio

Search Item:  Keywords:  Search

<input type="checkbox"/>	Radio Unit†	Radio Mode	Status	Operation
<input type="checkbox"/>	1	802.11n(5GHz)	Enable	
<input type="checkbox"/>	2	802.11n(2.4GHz)	Enable	

Enable Disable

### Configuration verification

- Select **Summary > Client** from the navigation tree to enter the page displaying online clients, as shown in [Figure 3-51](#).

**Figure 3-51** View online clients

Client

Search Item:  Keywords:

<input type="checkbox"/>	MAC Address	Wireless service	VLAN ID	IP Address	QoS Quality	Client Type	Client Rssi	Operation
<input type="checkbox"/>	001e-583f-0916	11nservice	1	-NA-	Y	802.11n (2.4GHz)		

```

Total Number of Clients      : 1
Total Number of Clients Connected : 1
Client Information
-----
MAC Address      : 001e-583f-0916
AID              : 126
Radio Interface  : WLAN-Radiol/0/2
SSID             : 11nservice
BSSID           : 0022-5755-fd09
Port            : WLAN-BSS1
  
```

### Configuration guidelines

When configuring 802.11n, note that:

- To modify the 802.11n radio setup and 802.11n rates, shut down the radio first.
- Select **Radio > Radio** from the navigation tree, select the AP to be configured, and click the corresponding icon to enter the radio configuration page, where you can modify the 802.11n-related parameters, including **Bandwidth Mode**, **A-MSDU**, **A-MPDU**, **Short GI**, and **Client 802.11n Only** (permitting only 802.11n users to access the wireless network).
- Make sure that 802.11n (2.4GHZ) is enabled.
- Select **Radio > Rate** from the navigation tree to modify the 802.11n rate.
- When satisfied with the configuration [Save Configuration to File](#) to ensure it is not lost when the Access Point restarts.

# 4 WDS Configuration


## WDS Configuration Example

### Network requirements

As shown in [Figure 4-1](#):

- AP 1 and AP 2 are connected to different LAN segments.
- The WDS link between AP 1 and AP 2 is formed in 802.11n (2.4GHZ) radio mode.

**Figure 4-1** Network diagram for WDS configuration



### Configuration procedure

- 1) Select a correct country/region code

Select **Advanced > Country/Region Code** from the navigation tree to enter the page for setting a country/region code, as shown in [Figure 3-2](#).

- 2) Configure WDS

Select **Wireless Service > WDS** from the navigation tree to enter the **WDS Setup** page, as shown in [Figure 4-2](#).

**Figure 4-2** WDS setup page

<input type="checkbox"/>	Radio Unit	Radio Mode	WDS Status	Operation
<input type="checkbox"/>	1	802.11n(5GHz)	Disable	
<input type="checkbox"/>	2	802.11n(2.4GHz)	Disable	

Explain : The operation of disabling WDS will cancel uplink configuration.

Find the radio unit to be configured in the list, and click the corresponding icon to enter the **WDS Setup** page shown in [Figure 4-3](#).

**Figure 4-3** WDS setup page

WDS Setup | WDS Global Setup

Radio Unit:  Radio Mode:

**Preshared Key**

Pass Phrase  Raw Key

Preshared Key:  \* character(8-63)

**Neighbor List**

Neighbor MAC Address:


Neighbor MAC Address	Indicator Light Control	Operation
----------------------	-------------------------	-----------

+ Advanced Setup

Items marked with an asterisk(\*) are required

- Select the **Pass Phrase** check box, and input **12345678** in the **Preshared Key** input box.
- Do not set the neighbor MAC address, indicating that the AP can establish a WDS link with any other AP.
- Click **Apply**.

3) Configure the same working channel.

Select **Radio > Radio** from the navigation tree, select the radio unit to be configured in the list, and click the corresponding  icon to enter the **Radio** page, as shown in [Figure 4-4](#).

**Figure 4-4** Configure the working channel

Radio

Radio Unit:  Radio Mode:

Transmit Power:  Channel:

**802.11n**

Bandwidth Mode:   Client 802.11n Only

A-MSDU  A-MPDU  Short GI

+ Advanced Setup

Items marked with an asterisk(\*) are required  
Info: Before setting 802.11n, disable the radio first.

Select the channel to be used from the **Channel** drop-down list.



# Enable 802.11n (2.4GHz) radio (By default, 802.11n (2.4GHZ) radio is enabled. Therefore, this step is optional. )

Select **Radio > Radio** from the navigation tree to enter the **Radio** page. Make sure that 802.11n (2.4GHz) is enabled.

4) Enable WDS

Select **Wireless Service > WDS** from the navigation tree to enter the **WDS Setup** page.

**Figure 4-5** WDS setup page

WDS Setup		WDS Global Setup		
<input type="checkbox"/>	Radio Unit	Radio Mode	WDS Status	Operation
<input type="checkbox"/>	1	802.11n(5GHz)	Disable	
<input checked="" type="checkbox"/>	2	802.11n(2.4GHz)	Disable	

Explain : The operation of disabling WDS will cancel uplink configuration.

Select the checkbox corresponding to 802.11n (2.4GHz), and click **Enable**.

**Configuration verification**

- Check the WDS link status.

Select **Summary > WDS** from the navigation tree to enter the page displaying WDS information.

**Figure 4-6** The page displaying WDS information

WDS			
Radio Unit	Radio Mode	WDS Status	Work Mode
1	802.11n(5GHz)	Disable	Bridge Mode
	802.11n(2.4GHz)	Enable	Bridge Mode

Neighbor Information

Search Item: Neighbor MAC Address Keywords:

Neighbor MAC Address	Local MAC Address	Link State	Link Uptime	Signal Quality
0022-5755-fd08	0033-6e16-8e01	UP	0: 0: 2	

**Configuration guidelines**

- The output information of a WDS link includes: neighbor MAC address, local MAC address, link state, link uptime, and signal quality.
- When five green bars are displayed for the signal quality, the signal is of the highest quality; if yellow bars are displayed, the signal is weak. In this case, you should check whether the antennas in use match the current radio, whether the antennas are connected correctly, and whether the maximum power of the current radio is too low.
- When satisfied with the configuration [Save Configuration to File](#) to ensure it is not lost when the Access Point restarts.

# WDS Point-to-Multipoint Configuration Example


## Network requirements

As shown in [0](#), it is required that AP 1 establish a WDS link with AP 2, AP 3, and AP 4 respectively.

The WDS configuration is the same as the normal WLAN WDS configuration. Note the following when configuring WDS:

- Configure a neighbor MAC address for each radio interface (otherwise, WDS links may be established between AP 2, AP 3 and AP 4).
- Set the maximum number of WDS links allowed. The default value is 2. It should be set to **3** for AP 1 in this example.

**Figure 4-7** Network diagram for WDS configuration



## Configuration procedure

WDS configuration is the same as normal WLAN WDS configuration. Refer to [WDS Configuration Example](#) for details.

## Configuration verification

Display WDS link status:

- It is displayed on the WDS link status page of AP 1 (which you can enter by selecting **Summary** > **WDS** from the navigation tree) that AP 1 has established a WDS link with AP 2, AP 3 and AP 4 respectively.
- It is displayed on the WDS link status page of AP 2, AP 3 and AP 4 (which you can enter by selecting **Summary** > **WDS**) that AP 2, AP 3 and AP 4 have respectively established a WDS link with AP 1.

## Configuration guidelines

When satisfied with the configuration [Save Configuration to File](#) to ensure it is not lost when the Access Point restarts.

# 5 Repeater Mode Configuration

## Repeater Mode Configuration Example

### Network Requirements


As shown in [Figure 5-1](#):

AP1 connects to the wired network. The AP acting as a repeater needs to set up a WDS link with AP 1. At the same time, the repeater needs to provide wireless access service for clients.

To satisfy the requirements above:

- Use the 802.11n (2.4GHz) radio to set up a WDS link between AP 1 and the repeater.
- Use the 802.11n (2.4GHz) radio to connect clients to the repeater.
- The channel of the WDS link between AP 1 and the repeater must be the same as that of the access service. In this example, channel 11 in 802.11n (2.4GHz) radio mode is used as the working channel.
- Configure WDS on AP 1. For the detailed configuration procedure, refer to [Configuration procedure](#).
- Configure WDS and access service on the repeater.

**Figure 5-1** Network diagram for repeater mode configuration



### Configuration procedure

Perform the following configurations on the repeater:

- 1) Select a correct country/region code

Select **Advanced > Country/Region Code** from the navigation tree to enter the page for setting a country/region code, as shown in [Figure 3-2](#).

- 2) Configuring WDS

Select **Wireless Service > WDS** from the navigation tree to enter the **WDS Setup** page shown in [Figure 5-2](#).

**Figure 5-2** WDS setup page

WDS Setup		WDS Global Setup		
<input type="checkbox"/>	Radio Unit	Radio Mode	WDS Status	Operation
<input type="checkbox"/>	1	802.11n(5GHz)	Disable	
<input type="checkbox"/>	2	802.11n(2.4GHz)	Disable	

Explain : The operation of disabling WDS will cancel uplink configuration.

Select the 802.11n radio mode in the list and click the corresponding icon in the **Operation** column to enter the page shown in [Figure 5-3](#).

**Figure 5-3** WDS setup page

WDS Setup		WDS Global Setup		
Radio Unit	<input type="text" value="2"/>	Radio Mode	<input type="text" value="802.11n(2.4GHz)"/>	
<b>Preshared Key</b>				
<input checked="" type="radio"/> Pass Phrase <input type="radio"/> Raw Key				
Preshared Key	<input type="text" value="*****"/> * character(8-63)			
<b>Neighbor List</b>				
Neighbor MAC Address	<input type="text"/>	<input type="button" value="Add"/>		
Neighbor MAC Address	Indicator Light Control	Operation		
+Advanced Setup				

Items marked with an asterisk(\*) are required

- Select the **Pass Phrase** option and input 12345678 in the **Preshared Key** text box.
- Click **Apply**.

3) Configuring the working channel

# Configure the working channel.

Select **Radio > Radio Setup** from the navigation tree, find the radio to be configured in the list, and click the corresponding icon to enter the page shown in [Figure 5-4](#).

**Figure 5-4** Configure the same channel

Radio

---

Radio Unit

Transmit Power

Radio Mode

Channel

802.11n

Bandwidth Mode

A-MSDU     A-MPDU     Client 802.11n Only     Short GI

+ Advanced Setup

---

Items marked with an asterisk(\*) are required  
Info: Before setting 802.11n, disable the radio first.

Select **11** in the **Channel** drop-down list.

# Enable 802.11n (2.4GHz) radio. (By default, 802.11n (2.4GHz) radio is enabled. Therefore, this step is optional. )

Select **Radio > Radio Setup** from the navigation tree to enter the **Radio Setup** page. Make sure that 802.11n (2.4GHz) is enabled.

4) Enabling WDS

Select **Wireless Service > WDS** from the navigation tree to enter the **WDS Setup** page shown in [Figure 5-5](#).

**Figure 5-5** WDS setup page

WDS Setup    WDS Global Setup

	Radio Unit	Radio Mode	WDS Status	Operation
<input type="checkbox"/>	1	802.11n(5GHz)	Disable	
<input type="checkbox"/>	2	802.11n(2.4GHz)	Disable	

Explain : The operation of disabling WDS will cancel uplink configuration.

Select the check box corresponding to 802.11n (2.4GHz) and click **Enable**.

5) Configuring the access service



### Note

For how to configure the access service on the repeater, refer to [Wireless Service Configuration Example](#). You can strictly follow the steps in [Wireless Service Configuration Example](#) to configure the access service on the repeater.

**Figure 5-6** Configure the access service

Access Service

Wireless Service Name  \* Chars. (1-32)

Wireless Service Type

Items marked with an asterisk(\*) are required



### Note

When configuring access service on the repeater, make sure that the radio mode of the repeater is the same as that of WDS.

### Configuration verification

# Verify that the WDS link has been established for the repeater.

Select **Summary** > **WDS** from the navigation tree to enter the **WDS** page displaying the WDS information, as shown in [Figure 5-7](#). Click radio unit 2 to see the neighbor information.

**Figure 5-7** The page displaying WDS information

WDS

Radio Unit	Radio Mode	WDS Status	Work Mode
1	802.11n(5GHz)	Disable	Bridge Mode
2	802.11n(2.4GHz)	Enable	Bridge Mode

Neighbor Information

▶ Search Item:  Keywords:

Neighbor MAC Address	Local MAC Address	Link State	Link Uptime	Signal Quality
0033-6e16-8e01	0022-5755-fd08	PROCESSING	0:0:0	

# Verify that the repeater mode has been configured successfully.

Select **Summary** > **Radio** from the navigation tree, and the page displaying radio information appears, as shown in [Figure 5-8](#). On the page, you can see that the 802.11n (2.4GHz) radio mode on the repeater provides both access and mesh services, and one user has accessed the wireless network through the repeater.

**Figure 5-8** The page displaying radio information

Radio								
<input type="checkbox"/>	Radio Unit	Status	Radio Mode	Channel	Power (dBm)	Service Type	Res Using Ratio(%)	Noise Floor (dBm)
<input type="checkbox"/>	1	Up	802.11n (5GHz)	153	19	-	0	-94
<input type="checkbox"/>		Up	802.11n (2.4GHz)	11	16	Access,WDS	11	-68

Wireless Service		Detail Info	
Wireless Service	Status	Client Number	
repeater	Enable	1	

### Configuration guidelines

When satisfied with the configuration [Save Configuration to File](#) to ensure it is not lost when the Access Point restarts.

# 6 Workgroup Bridge Mode Configuration

## Workgroup Bridge Mode Configuration Example


### Network requirements

As shown in [Figure 6-1](#), an AP working as a workgroup bridge accesses the wireless network as a client. The Ethernet interface of the workgroup bridge connects to multiple hosts or printers in the wired network, and thus the wired network is connected to the wireless network through the workgroup bridge.

The detailed requirements are as follows:

- The AP accesses the wired LAN, and the workgroup bridge with MAC address 000f-e2333-5510 accesses the AP as a client.
- The workgroup bridge accesses the wireless service **psk** by passing the RSN(CCMP)+PSK authentication.
- Client with MAC address 0014-6c8a-43ff also accesses the wireless service **psk**.

**Figure 6-1** Network diagram for workgroup bridge mode configuration



### Configuration procedure

- 1) Select a correct country/region code

Select **Advanced > Country/Region Code** from the navigation tree to enter the page for setting a country/region code, as shown in [Figure 3-2](#).

- 2) Enable the client mode

Select **Wireless Service > Client Mode** from the navigation tree and click **Connect Setup** to enter the page shown in [1](#).



**Figure 6-2** Enable the client mode

Connect Setup    Statistic Information

Radio Setup

	Radio Unit	Radio Mode	Client State
<input type="checkbox"/>	1	802.11n(5GHz)	Disabled
<input type="checkbox"/>	2	802.11n(2.4GHz)	Disabled

Select the check box corresponding to 802.11n (2.4GHz) and click **Enable**. With the client mode enabled, you can check the existing wireless services in the wireless service list.

**Figure 6-3** Check the wireless service list

SSID List

Wireless Service Name	Connection State	Signal Quality	Operation
h06532-psk4	Disconnected		[Connect][Disconnect]
luwei-test3	Disconnected		[Connect][Disconnect]
mge_test	Disconnected		[Connect][Disconnect]
wb2360	Disconnected		[Connect][Disconnect]
z06431-psk	Disconnected		[Connect][Disconnect]

3) Connect the wireless service

Click the **Connect** icon of the wireless service **psk** in the wireless service list, and a **SET CODE** dialog box shown in [Figure 6-4](#) appears.

**Figure 6-4** SET CODE

**SET CODE**

AuthMode

CipherSuit

Password

KeyID  (used in WEP)

- Specify the **AuthMode** as **RSN+PSK**.
- Specify the **CipherSuite** as **CCMP**.
- Set the **Password** to that on the AP, **12345678**.
- Click **Apply**.

## Configuration verification

On the AP shown in [Figure 6-1](#), select **Summary** > **Client** from the navigation tree to enter the page shown in [Figure 6-5](#), where you can check that the workgroup bridge is online.

**Figure 6-5** Check that the workgroup bridge is online


<input type="checkbox"/>	MAC Address	Wireless service	VLAN ID	IP Address	QoS Quality	Client Type	Client Rssi	Operation
<input type="checkbox"/>	000f-e233-5510	psk	1	192.168.0.3	Y	802.11n(5GHz)		
<input type="checkbox"/>	0014-6c8a-43ff	psk	1	192.168.0.1	Y	802.11n(2.4GHz)		

- You can see that the client with MAC address 0014-6c8a-43ff and the workgroup bridge with MAC address 000f-e2333-5510 have been successfully associated with the AP.
- The wired devices on the right (such as printers and PCs) can access the wireless network through the workgroup bridge.

## Configuration guidelines

- As shown in [Figure 6-6](#), if the workgroup bridge uses two radio interfaces at the same time, the client connecting to radio 2 can access the AP through the workgroup bridge.

**Figure 6-6** Network diagram for a workgroup bridge using two radio interfaces at the same time



- When satisfied with the configuration [Save Configuration to File](#) to ensure it is not lost when the Access Point restarts.

# 7 Save Configuration over reboot

## Save Configuration to File

To avoid losing the applied configuration changes when the Access Point reboots:

Select **Device> Configuration** from the navigation tree, and then click the **Save** tab to enter the save configuration confirmation page, as shown in [Figure 7-1](#).

- Click the **Save Current Settings** button to save the current configuration to the configuration file.


**Figure 7-1** Save configuration confirmation



**Note:** Click **Save Current Settings** to save the current configuration.

- Or Click the **Save** button on the right of the title area to save the current configuration to the configuration file.

**Figure 7-2** Save configuration confirmation



The configuration from the last saved current settings will be installed from the configuration file (**.cfg** file or **.xml** file) at the next startup. Any settings applied but not saved to the configuration file will be lost when the Access Point next restarts.

---



**Note**

- Saving the configuration takes a period of time.
  - The system does not support the operation of saving configuration of two or more consecutive users. If such a case occurs, the system prompts the latter users to try later.
-